




Patent #6,253,416 and other patents pending
BILLY GOAT FORCE BLOWER
F1801V

Owner's Manual

Accessories

<p>HOLD DOWN KIT</p> <p><i>To secure blower for transportation on trailer floors.</i></p> 
<p>P/N 440120</p>

<p>PARKING BRAKE</p> <p><i>Effective and Easy to use to prevent blower from rolling.</i></p> 
<p>P/N 440140</p>



ABOUT THIS MANUAL

THANK YOU for purchasing a BILLY GOAT® *FORCE Blower*. Your new machine has been carefully designed and manufactured to provide years of reliable and productive service. This manual provides complete operating and maintenance instructions that will help to maintain your FORCE Blower in top running order. Read this manual carefully before assembling, operating, or servicing your equipment.

CONTENTS

SERIAL PLATE DATA AND SPECIFICATIONS _____	3
GENERAL SAFETY _____	4-5
SOUND AND VIBRATION _____	6
INSTRUCTION LABELS _____	7
PACKING CHECKLIST _____	8
ASSEMBLY _____	9
OPERATION _____	10-11
MAINTENANCE _____	12
TROUBLESHOOTING AND WARRANTY PROCEDURE _____	13
ILLUSTRATED PARTS LIST _____	14
PARTS LIST _____	15
MAINTENANCE RECORD _____	16




FORCE BLOWER 18 Owner's Manual

SERIAL PLATE DATA

Record the model number, serial number, date of purchase, and where purchased.

Purchase Date: _____

Purchased From: _____



Specifications

F1801V

Engine: HP	18 HP (13.42kW)
Engine: Model	3564420224E9
Engine: Type	B & S VANGUARD
Engine: Fuel Capacity	9 qt. (8.52L)
Engine: Oil Capacity	1.75 qt. (1.66L)
Total Unit Weight:	179 # (81.2Kg)
Overall Length:	58" (1.43m)
Overall Width	29.25" (0.74m)
Overall Height	45" (1.14m)
In compliance with 2000/14/EEC standards	117dB(a)
Sound at Operator's ears	97dB(a)
Vibration at operator position	1.2 g (11.9 m/s ²)



GENERAL SAFETY INSTRUCTIONS and SYMBOLS

The safety symbols shown below are used throughout this manual. You should become familiar with them before assembling, operating, or servicing this equipment.



WARNING: This symbol indicates important information that will prevent injury to yourself or others.



This symbol indicates ear protection is recommended when operating this equipment.



This symbol indicates eye protection is recommended when operating this equipment.



This symbol indicates gloves should be worn when servicing this equipment.



This symbol indicates that this manual and the engine manufacturer's manual should be read carefully before assembling, operation, or servicing this equipment.



CAUTION: This symbol indicates important information that will prevent damage to your BILLY GOAT[®] FORCE Blower.



This symbol indicates the engine oil level should be checked before operating this equipment.

Read and make sure you thoroughly understand the following safety precautions before assembling, operating or servicing this equipment:



READ this manual and the engine manufacturer's manual carefully before assembling, operating, or servicing this equipment.



EAR PROTECTION is recommended when operating this equipment.



EYE PROTECTION is recommended when operating this equipment.



BREATHING PROTECTION is recommended when operating this equipment.



WARNING: **EXHAUST** from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.


DO NOT operate this equipment on any unimproved forested, brushy, or grass covered land unless a spark arrester is installed on the muffler as required by Section 4442 of the California Public Resources Code. The arrester must be maintained in good working order. Other states may have similar laws. Federal laws apply on federal lands.


DO NOT run engine in an enclosed area. Exhaust gases contain carbon monoxide, an odorless and possibly fatal poison.





FORCE BLOWER 18 Owner's Manual





WARNING:  **DO NOT** run this equipment indoors or in any poorly ventilated area. Refueling outdoors is recommended.


 **DO NOT** refuel this equipment while the engine is running. Allow engine to cool for at least two minutes before refueling.


 **DO NOT** store gasoline near an open flame.


 **DO NOT** remove gas cap while engine is running.


 **DO NOT** start or operate engine if strong odor of gasoline is present.


 **DO NOT** start or operate engine if gasoline is spilled. Move equipment away from spill until gasoline has completely evaporated.


 **DO NOT** smoke while filling the fuel tank.

 **DO NOT** check for spark with spark plug or spark plug wire removed. Use an approved spark tester.


 **DO NOT** operate engine without a muffler. Inspect muffler periodically and replace if necessary. If equipped with muffler deflector, inspect deflector periodically and replace if necessary.

 **DO NOT** operate engine with grass, leaves or other combustible material near the muffler.

 **DO NOT** touch muffler, cylinder, or cooling fins when hot. Contact with hot surfaces may cause severe burns.


 **DO NOT** leave equipment unattended while in operation.


 **DO NOT** park equipment on a steep grade or slope.

 **DO NOT** operate equipment with bystanders in or near the work area.

 **DO NOT** allow children to operate this equipment.

 **DO NOT** operate equipment with guards removed.

 **DO NOT** operate equipment near hot or burning debris or any toxic or explosive materials.

 **DO NOT** operate equipment on slopes greater than specified in Specifications section of this manual.

ALWAYS remove spark plug wire when servicing equipment to prevent accidental starting.

ALWAYS check fuel lines and fittings frequently for cracks or leaks. Replace if necessary.

ALWAYS keep hands and feet away from moving or rotating parts.

ALWAYS store fuel in approved safety containers.



WARNING: Important

Do not run this machine without director cone attached or with improper air director cone.




DO NOT run this machine with a cracked or damaged impeller under any circumstances.



SOUND

 **L_{WA}**
117 dB SOUND LEVEL 97 Db(a) at Operators Position

Sound tests were conducted in accordance with 2000/14/EC, as well as ISO 11094, and were performed on 12-12-2006 under the conditions listed below.

 Sound power level listed is the highest value for any model covered in this manual. Please refer to serial plate on the unit for the sound power level for your model.

General Conditions:	Sunny
Temperature:	40.4°F (4.7°C)
Wind Speed:	6.1 mph (9.9kph)
Wind Direction:	Southwest
Humidity:	93.6%
Barometric Pressure:	30Hg (101.85kpa)

VIBRATION DATA


VIBRATION LEVEL 1.2g (11.9m/s²)

Vibration levels at the operator's handles were measured in the vertical, lateral and longitudinal directions using calibrated vibration test equipment. Tests were performed on 12-13-2006 under the conditions listed below.

General Conditions:	Sunny
Temperature:	57.2°F (14.3°C)
Wind Speed:	11.8 mph (19.1kph)
Wind Direction:	South
Humidity:	46.4%
Barometric Pressure:	30.1Hg (101.96kpa)

INTENDED USE

This machine is designed for cleaning outdoor surfaces, where the debris can be effectively blown into a consolidated area for convenient pickup and removal.

 **DO NOT** operate if excessive vibration occurs. If excessive vibration occurs, shut engine off immediately and check for damaged or worn impeller, loose impeller bolt, loose impeller key, loose engine or debris stuck in fan or housing. Note: See parts list for proper impeller bolt torque specifications. (See trouble shooting section on page 13).



INSTRUCTION LABELS

The labels shown below were installed on your BILLY GOAT® FORCE Blower. If any labels are damaged or missing, replace them before operating this equipment. Item numbers from the Illustrated Parts List and part numbers are provided for convenience in ordering replacement labels. The correct position for each label may be determined by referring to the Figure and Item numbers shown.




LABEL READ OWNERS MANUAL
ITEM #44 P/N890301



LABEL EAR EYE BREATHING
ITEM# 45 P/N890254



DANGER FLYING DEBRIS
ITEM # 46 P/N 810736



LABEL EXPLOSIVE FUEL
ITEM # 43 P/N 400268





LABEL THROTTLE CONTROL
ITEM # 42 P/N 810656

ENGINE LABELS

BRIGGS AND STRATTON VANGUARD

ENGINE MAINTENANCE	
1. CHECK OIL LEVEL	8 HOURS
2. CHECK & CLEAN AIR CLEANER	25 HOURS
3. CHANGE OIL	50 HOURS
4. REPLACE OIL FILTER	100 HOURS
5. CLEAN COOLING FINS	100 HOURS

See Operating and Maintenance Instructions





PACKING CHECKLIST

These items should be included in your carton. If any of these parts are missing, contact your dealer.
Your BILLY GOAT® *FORCE Blower* was shipped in one carton, completely assembled except for the Upper Handle Assembly and Front Diverter. Mounting hardware for the Upper Handle Assembly can be found in the parts bag.



READ all safety instructions before assembling unit.

TAKE CAUTION when removing the unit from the box the Handle Assembly is attached to the unit by cables.



PUT OIL IN ENGINE BEFORE STARTING

PARTS BAG & LITERATURE ASSY

Warranty card P/N- 400972, Owner's Manual P/N-440179, Declaration of Conformity P/N-440022, Handle Hardware-Items #10(washer 8171003), #11(locknut 8160002), #36(cap screw 8041032), #74 (Ty-wrap 900407).



Boxing Parts Checklist


- Handle Upper Assembly
Item #30 P/N-440035
- Parts Bag & Literature Assy
P/N-440166
- B & S Vanguard 18 hp


ASSEMBLY

1. Follow the steps in figures A and B, then securely tighten all hardware shown.
2. Connect spark plug wire.

Figure A

The hardware for attaching the upper handle to the lower is in the parts bag. Install upper handle (item 30), to preassembled lower handle (item 28) by sliding the upper over and down the outside of the lower handle. Using bolt (item #36), washers (item #10) & lock nut (item #11) to install upper handle to lower handle. Finish installing the other side of the upper handle assembly using screw and lock nut provided.







TOOLS REQUIRED
Two 1/2" open ended wrenches

Figure B

The throttle control and Aim-and-Shoot™ will be attached to the throttle arm on the engine and wrapped around the engine for shipping. Unwrap and secure throttle control (item #31) to upper handle with screws (item #17). Screws will already be mounted in handle, simply remove and use to mount the throttle control securing the cable with two Ty-wraps.






TOOLS REQUIRED
One 3/8 open ended wrench




OPERATION

 Like all mechanical tools, reasonable care must be used when operating machine.

Inspect machine work area and machine before operating. Make sure that all operators of this equipment are trained in general machine use and safety.

 **PUT OIL IN ENGINE BEFORE STARTING**

STARTING

 **ENGINE:** See engine manufacturer's instructions for type and amount of oil and gasoline used. Engine must be level when checking and filling oil and gasoline.

FUEL VALVE: Move fuel valve to "ON" position (when provided on engine).

STOP SWITCH: Located on the engine. "ON" position.

CHOKE: Operated with choke lever on side of engine.

THROTTLE: Controlled by throttle lever on the handle. Move remote throttle control to fast position. Pull starting rope to start engine.


ENGINE SPEED: Under normal conditions, operate at minimum throttle to accomplish your current cleaning task.



IF YOUR UNIT FAILS TO START:

See Troubleshooting on page 13.

HANDLING & TRANSPORTING:

Using two people to lift machine is recommended. Lift holding the handle and handle brace. Secure in place during transportation. See unit specifications on page 3 for unit weight.

 Do not use the front grill as an anchor point when securing the unit for transport.

  Never lift the machine while the engine is running.

BLOWING OPERATION


Your Billy Goat Force blower is equipped with an air director cone and the patented Aim-and-Shoot™ control lever to allow the operator to direct the air stream up or down as required to assist in moving debris. This feature is extremely useful when debris has piled up to the point that it cannot be blown any farther. The air stream can be directed upward to blow the top of the debris pile over and allow the operator to continue moving more debris farther.



ADJUSTING AIR DIRECTOR

To adjust air direction, squeeze Aim-N-Shoot™ control lever. When you want to blow debris at the same angle for an extended period, choose a suitable position and use the finger controlled push button lock to lock the cone in position. For operations that do not require the use of the Aim-N-Shoot™ feature the front adjustment knob, pictured below, can be used to permanently lock the cone into position. NOTE: be sure to release the knob when returning to using the Aim-N-Shoot™.

⚠ DO NOT position director cone to where it will blow debris towards people, vehicles or other objects in vicinity. Flying debris may damage, harm, or cause injury to people or objects in air flow range.





MAINTENANCE

PERIODIC MAINTENANCE

Periodic maintenance should be performed at the following intervals:

Maintenance Operation	Every Use	Daily or Every 5 Hours	Every 25 Hours	Every 50 Hours	Every 100-150 Hours
Inspect for worn or damaged parts.	•				
Check for excessive vibration		•			
Inspect Impeller for cracks or damage					•
Inspect for loose parts.		•			

IMPELLER REMOVAL

1. Wait for engine to cool and disconnect spark plug.
2. Remove housing front cover, by removing (11) bolts and nuts, items #13 & #14, around outside of front cover.
3. Remove impeller bolt (item #35), lock washer (item #27) and washer (item #34).
4. DO NOT pry on impeller. Pull on center hub area only of impeller. If impeller slides off freely, proceed to (step 6).
5. If the impeller does not loosen, obtain a 3/4-16x3" (Billy Goat part #440192) or longer bolt. Thread bolt by hand into nut until bolt rests against the shaft. Tighten the bolt slowly, which will pull the impeller away from the shaft, remove impeller from shaft. *Using a penetrating oil can help loosen a stuck impeller.*
6. Reinstall new impeller in reverse order of removal.
7. Tighten impeller bolt. Torque impeller bolt (see parts list on page 15 for proper impeller bolt torque specifications).

TIRE AIR PRESSURE

Check at regular intervals and maintain.

Front Tires - 24 Psi (165 kPa).

Rear Tires - 20 Psi (137 kPa).

STORAGE

⚠ Never store engine indoors or in enclosed poorly ventilated areas with fuel in tank, where fuel fumes may reach an open flame, spark or pilot light, as on a furnace, water heater, clothes dryer or other gas appliance.

If engine is to be unused for 30 days or more, prepare as follows:

⚠ Remove all gasoline from carburetor and fuel tank to prevent gum deposits from forming on these parts and causing possible malfunction of engine. Drain fuel outdoors, into an approved container, away from open flame. Be sure engine is cool. Do not smoke. Run engine until fuel tank is empty and engine runs out of gasoline.

NOTE Fuel stabilizer (such as Sta-Bil™) is an acceptable alternative for minimizing the formation of gum deposits during storage. Add stabilizer to gasoline in storage container or fuel tank. Follow stabilizer manufacturer's instructions to determine proper mix ratio. Run engine at least 10 minutes after adding stabilizer to allow it to reach carburetor.



TROUBLESHOOTING

Problem	Possible Cause	Solution
Abnormal vibration.	<ul style="list-style-type: none"> · Loose or out of balance impeller. · Loose engine. 	<ul style="list-style-type: none"> · Check impeller and replace if required. · Check engine.
Engine will not start.	<ul style="list-style-type: none"> · Engine not in full choke position. · Out of gasoline or bad, old gasoline. · Spark Plug wire disconnected. · Gas valve off. · Dirty air cleaner. 	<ul style="list-style-type: none"> · Check choke position. · Check gasoline. · Connect spark plug wire. · Turn on gas valve. · Clean or replace air cleaner. Contact a qualified service person.
Engine is locked, will not pull over.	<ul style="list-style-type: none"> · Engine problem. 	<ul style="list-style-type: none"> · Contact an engine servicing dealer for engine problems.
Aim-N-Shoot™ lever sticking	<ul style="list-style-type: none"> · Debris stuck around cone · Cone adjustment knob too tight · Adaptor mount nut (item 38) too tight 	<ul style="list-style-type: none"> · Clean debris · Apply silicone based lubricant to pivot points · Loosen knob · Loosen nut

When servicing engine refer to specific manufacturers engine owner's manual. Engine warranty is covered by the specific engine manufacturer. If your engine requires warranty or other repair work contact your local servicing engine dealer. When contacting a dealer for service it is a good idea to have your engine model number available for reference (See table page 3). If you cannot locate a servicing dealer in your area you can contact the manufacturers national service organization.

To reach:

Briggs and Stratton: 800-223-3723

WARRANTY CLAIM PROCEDURE


Should a BILLY GOAT® machine fail due to a defect in material and/or workmanship, the owner should make a warranty claim as follows:

- The machine must be taken to the dealer from whom it was purchased or to an authorized Servicing BILLY GOAT Dealer.
- The owner must present the remaining half of the Warranty Registration Card, or, if this is not available, the invoice or receipt.
- The Warranty Claim will be completed by the authorized BILLY GOAT Dealer and submitted to their respective BILLY GOAT Distributor for their territory Attention: Service Manager. Any parts replaced under warranty must be tagged and retained for 90 days. The model number and serial number of the unit must be stated in the Warranty Claim.
- The distributor service manager will sign off on the claim and submit it to BILLY GOAT for consideration.
- The Technical Service Department at BILLY GOAT will study the claim and may request parts to be returned for examination. BILLY GOAT will notify their conclusions to the distributor service manager from whom the claim was received.
- The decision by the Technical Service Department at BILLY GOAT to approve or reject a Warranty Claim is final and binding.

For online product registration go to www.billygoat.com



ILLUSTRATED PARTS LIST





FORCE BLOWER 18 Owner's Manual

PARTS LIST

F 1801V			
ITEM NO.	DESCRIPTION	PART NUMBER	QTY.
1	ENGINE 18 VANGUARD	440173	1
2	BASE ENGINE WA	440011	1
3	SPACER RING ENGINE	440174	1
4	PLATE REINFORCE HOUSING	440010	2
5	HOUSING FRONT MOLDED	440023	1
6	HOUSING BACK MOLDED	440024	1
7	WASHER LOCK 3/8 TWISTED TOOTH	400502	4
8	SCREW CAP 3/8-16X1 1/2 ZP	8041052	4
9	ROD HAND STOP	440057	1
10	WASHER 5/16 FLAT WASHER Z/P	8171003	20
11	NYLON INSERT LOCKNUT 5/16-18	8160002	10
12	SCREW CAP 5/16-18 X 1.75 ZP	8041031	3
13	SCREW CAP 1/4-20 x 1 1/2	8041008	11
14	NUT FLANGE 1/4-20	900455	11
15	WHEEL & TIRE 13" X 5" PNEUMATIC	440054	2
16	RING RETAINING 3/4	850230	2
17	SCREW SM 1/4 x 1 DRILL PT.	430208	2
18	WHEEL ASSY 10" PNEUMATIC	400295	1
19	SPACER FRONT AXLE	440050	1
20	SPACER LH WHEEL	440052	1
21	SPACER RH WHEEL	440051	1
22	SCREW CAP 1/2-13 x 7"	8041235	1
23	WASHER FLAT 1/2" SAE	8172011	1
24	WASHER W/BOLT WA	440075	1
25	KNOB 3/8-16 SOLID HUB	811230	1
26	WASHER 2.25 OD x .515 ID x .134 ZP	610308-P	1
27	WASHER LOCK 3/8 S/T MED	8177012	1
28	HANDLE LOWER	440034	1
29	NYLON INSERT LOCKNUT 1/2-13	8160005	1
30	HANDLE UPPER	440035	1
31	CONTROL THROTTLE	440013	1
32	CABLE THROTTLE CONTROL	440178	1
33	NUT LOCK 3/8-16 LT W T THIN ZP	8161042	1
34	WASHER 1.5 O.D. X 0.453 X 0.5	440176	1
35	SCREW CAP 3/8 - 24 X 4 1/2" GR. 8 (33-38 ft. lbs)	440208	1
36	SCREW CAP 5/16"-18 X 2" ZP	8041032	7
37	DIRECTOR CONE 6"	440170	1
38	NUT LOCK 1/4" - 20 HEX ZP	8160001	6
39	SCREW SM #10-24X1/2" DRILL POINT	8122064	2
40	IMPELLER ASSEMBLY 17"	440236	1
41	GRILL FRONT BLOWER	440171	1
42	LABEL THROTTLE CONTROL	810656	1
43	LABEL HOT ENGINE	400268	1
44	LABEL READ	890301	1
45	LABEL EAR EYE BREATHING	890254	1
46	LABEL DANGER FLYING DEBRIS	810736	1
47	GRIP 1-1/4" ID x 13"	440012	1
48	LABEL FORCE	440172	1
49	HANDLE ASSY UPPER	440104	1
50	KEY 1/4" SQ X 2.25	9201123	1
51	GUARD MANIFOLD	811059	1
52	GUARD MUFFLER	811058	1
53	WASHER FLAT 1/4	8171002	5
54	HANDLE DIVERTER FORCE	440119	1
55	PIN LATCH DIVERTER	440118	1
56	SPRING COMPRESSION 0.281 X 0.88	440129	1
57	RING RETAINING .122 DIA	440125	1
58	SADDLE UPPER DIVERTER	440115	1
59	PLATE LOCK DIVERTER	440116	1
60	SCREW PLASTITE #6-19 X 5/8"	440126	2
60	SCREW PLASTITE #6-19 X 5/8"	440126	2
61	SADDLE LOWER DIVERTER	440114	1
62	SCREW PLASTITE #10-14 X 1"	440132	2
63	PIN PIVOT DIVERTER CONTROL	440123	1
64	RING RETAINING 5/16	430327	1
65	CABLE ASSY	440117	1
66	DIVERTER PIVOT ADAPTOR	440121	1
67	SPRING EXTENSION 0.468 X 5.25	440130	1
68	BRACKET DIVERTER FORCE	440127	1
69	PIN CLEVIS 1/4 X 3/4	440124	1
70	.051 X 3/4" HITCH PIN CLIP	440193	1
71	SCREW TCS #12-24 X 5/8" TYPE 1	440147	2
72	ADAPTOR MOUNT WA	440122	1
73	GRIP 1-1/4" ID x 9.5" LONG	440146	1
74	TY-WRAP	900407	5
75	SPACER 1" ID X 2" OD X 0.890 TK	830112	1
76	SPACER 1" ID X 2" OD X 0.265 TK	830113	1
77	VIBRATION LABEL	440191	1
78	SCREW SELF TAP 1/4" - 20 X 5/8"	890359	1
79	FORCE WHEEL BEARING .751 ID	440055	2

