

1803 S.W. Jefferson sreet Lee's Summit, Mo. 64082 / USA (816) 524-9666 FAX (816) 524-6983

Purpose: To allow easy unloading of a truck by swinging the loader out of the way. It allows the operator to reach further from the side of the truck when locked in 90° position.



DO NOT remove both pins simultaneously.




ALWAYS transport with swing away hitch in closed position.




USE ONLY with hitch rated class III or better.



## **INSTALLATION** of DL on Swing Away Hitch



Attach the DL to the Swing Away Hitch using the hardware provided (items 1-3)





## **OPERATION**



Normal operating position / Transport position **NOTE:** Do not transport with the hose in place.




To access the tailgate, remove the left pivot pin and rotate the arm with the loader and lock in place using the left pivot pin.






For easy curb side pick up, lock in place at 90° to right or left sides.


## REFERENCE PARTS



812290 HITCH PIVOT SAH ASSEMBLY (QTY 1)



811162 HITCHTONGUE SAH ASSEMBLY (QTY 1)



(QTY 1)